

KEEP IT GAME-READY

# BOARD CARE



## WARNING: NO ALCOHOL. EVER.

Never clean your board with rubbing alcohol, hand sanitizer, bleach, acetone or solvent sprays. They smear and strip the print, and it doesn't come back.

## CLEAN IT

### SOAP & WATER

Mild dish soap and lukewarm water on a soft microfiber cloth. Rinse with a damp cloth, then let it air-dry.

### NO SCRUBBING

No brushes, scouring pads, magic erasers or paper towels. Never pressure-wash.

## ROLL IT ROLL-OUT BOARDS

### GAME FACE OUT

Always roll it with the game face on the outside, so it lays flat and the edges hug the floor.

### ROLL IT LOOSE. NEVER FOLD.

Roll it around a wide tube. A fold or crease never comes back out.

## STORE IT

### NEVER STORE IT WET

Dry it completely first. Keep it out of basements, sheds and damp closets.

### KEEP IT COOL

No hot cars, attics or radiators. Heat warps it and makes the layers stick together.

### NOTHING ON TOP

Stand the box on its end or keep it on a shelf.

## BEFORE YOU PLAY

### LET IT WARM UP

Been in the cold? Bring it to room temperature before you unroll it.

### LAY IT FLAT

Unroll it game face up. Still curling? Give it a few hours flat on the floor.

## SCHOOLS & PROGRAMS

### SOCKS OR CLEAN SHOES

Grit under shoes is what wears a board down.

### NEED TO DISINFECT?

Use an alcohol-free, bleach-free product, and test it on the black edge first.

Take care of your board and it runs the block for years.

